


MAXHUB Smart Pen

Model: SP30B



Quick Start Guide

V1.0

MAXHUB

Table of Contents

I. Package Contents02

II. Product Introduction02

III. Pairing.....03

Safety Instructions

Before operating this product, read and follow the instructions carefully to avoid dangerous or illegal operations.

1. Operating Environment

- Do not use the device in damp or humid locations to avoid internal circuit damage.
- Avoid hot environments or areas with direct sunlight.
- Optimal temperature range for use: 0-40°C, humidity range: 10%-90% RH.

2. Child Safety

The device and its parts may include small components. Keep them out of reach of children to prevent accidents.

3. Battery

- Do not let children touch the battery.
- Avoid exposing the battery to fire to prevent fire hazards.
- Use the correct poles when connecting the battery to avoid short circuits.

4. Water Protection

This device is not waterproof. Keep the equipment dry.

5. Maintenance

- All maintenance should be carried out by qualified personnel. If the device malfunctions, do not disassemble it yourself.
- Avoid inserting objects into any of the ports to prevent damage.
- Do not drop or subject it to strong impacts or vibrations to avoid product damage.

Special Statements


- Intellectual Property Rights: The hardware design and software of this product are protected by copyright law. Unauthorized copying of the manual or any part of the product will subject violators to legal consequences.
- This manual is for reference only. The final actual functions are subject to the functions of the product ordered and received by the customer.
- The images are for reference only. Please refer to the actual product. Our company reserves the right to improve and change the product's appearance and design without prior notice.

I. Package Contents

Please check the following contents included in the package:

- 1. SP30B smart pen × 1
- 2. AAA battery × 1
- 3. Pen tip × 2

II. Product Introduction

	No.	Items	Description
	1*	LED Indicator	Displays the received signal.
	2	Function Key	1. Press once: Left mouse button 2. Press and hold for at least 2 seconds: Virtual laser
	3	Up	Press once: PPT/WPS page up
	4	Down	Press once: PPT/WPS page down
	/	Up + Down	Press Up and Down buttons simultaneously for 5 seconds: Clear pairing

* LED Indicator Status Instruction:

No.	Indicator Status	Description
1	Blue	Battery level > 20%
2	Red	Battery level ≤ 20%
3	Blue flashing	Smart pen awaiting pairing
4	Red, green and blue flashing in sequence	Factory reset

III. Pairing

1. Hold the pen close to the interactive display;
2. Wait for the "Pair pop-up" in the lower right corner of the interactive display;
3. Click "Pair". When the "Pairing Successful" message appears, pairing is complete;
4. If pairing unsuccessful, press and hold the "Page Up" + "Page Down" buttons simultaneously for more than 5 seconds until the LED indicator light flashes in red, green and blue sequence. Then repeat steps 1-3.



WARNING

If the battery is depleted, please purchase a qualified battery for replacement.

If not used for an extended period, remove the battery to prevent leakage or swelling. Otherwise, it may obstruct the pen tube.

